


挂脖风扇

— 说明书 —

外观说明



产品特点

- 轻便小巧,解放双手,随身携带。
- 多档位风力输出,满足不同使用场景。
- 无叶式简约设计,使用更加安心。
- 内置电池,超强续航。

使用方法


A. 使用方式

将风扇左右微微张开,出风口方向朝上,挂至脖上,按下开机键,风扇开始工作,风从出风口吹向头部,带来清凉体验。

B. 开关/模式切换


开关:
短按按键开机,长按按键关机。

风扇模式切换:
短按按键切换一档/二档/三档/关机模式。



C. 清洁保养

- 对本产品进行清洁前,请确保电源已被切断。
- 用干抹布擦拭风扇机身和出风口。
- 禁止用水或其他液体清洗电器部分(如电机、电源开关等)。
- 禁止用湿润的手或抹布触碰电源及电器部件。
- 出风口处有灰尘或异物请及时清理,避免灰尘掉入风腔内部。



D. 充电说明

本产品内置电池,超长续航。
指示灯状态说明

指示灯状态	含义
红灯灭灯	已充满电
红灯常亮	给风扇充电中
绿灯常亮	风扇工作状态
灯不亮	关机或风扇缺电停止工作

注意事项

- 使用时,头发应避免开进风口,以免头发卷入风腔内部,危及自身安全和影响产品寿命。
- 风扇在正常情况下使用时,当绿灯灭灯表示剩余电量过低,需要给设备充电。
- 请不要过度用力打开或弯折TPE软管,避免对产品造成损坏。
- 电池禁止拆解、撞击、挤压或投入火中。若出现严重鼓胀,请勿继续使用。请勿置于高温环境中。

警告

- 本产品使用锂离子电池,无记忆功能,过充或过放都将影响产品使用寿命,请及时充电及充满电后断开电源。
- 风扇工作时扇叶高速旋转,请勿将手指伸入其中,以免发生危险。
- 本产品非儿童玩具,14岁以下孩童,请在监护人看护下使用。
- 请勿挤压、拆解电池或将电池长期置于高温环境(60°及以上),否则可能会有漏液或爆炸危险。
- 请勿在充电时使用本产品。

产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
塑料件	○	○	○	○	○	○
金属件	○	○	○	○	○	○
硅胶件	○	○	○	○	○	○
PCB	x	○	○	○	○	○

本表格依据SJ/T 11364-2014的规定编制
○ 表示该有害物质在部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
x 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572规定的限量要求。

⑩ 本标识的数字表示产品在正常使用状态下的环保使用期限为10年

三包凭证

- 请妥善保管保修卡,以作维修时的凭证。
- 保修期为产品购买之日起一年内。
- 保修期内,本产品在正常使用的情况下发生故障,经本公司查验属实,将免费提供维修和换新服务。

以下情况恕不提供免费维修

本公司产品实行保修年限之内的有限保修。
属于下列情况的设备故障或损坏,不在有限保修之列,本公司不承担免费的保修义务:

- 设备或部件已经超出了有效的保修期;
- 客户未按照说明书的要求,错误的安装、保管以及使用而造成的设备故障或损坏;
- 非由本公司授权机构或人员拆卸而造成的设备故障或损坏;
- 因意外因素或人为原因(包括但不限于操作失误、刮伤、搬运、磕碰、输入不合适的电压电流等)导致的设备故障或损坏;

产品参数

产品名称: 挂脖风扇
输入: 5.0V≈1.0A
电 芯: 锂离子电池
功 率: 3W(MAX)
产品重量: 250g
充电时间: 约3-5小时(根据内置电池而定)
工作时间: 3-16小时(根据不同档位/使用场景而定)
执行标准: GB4706.1-2005、GB4706.27-2008
产品尺寸: 200(L)×192(W)×60(H)mm

包装配件

挂脖风扇*1
Type-c充电线*1
说明书*1
CPE袋*1

合格证
检测员 01 Pass

本说明书的内容及产品的规格技术说明如有变更,恕不另行通知


产品保修卡

产品型号: _____
购买日期: _____
代理商: _____
发票日期: _____
电 话: _____
顾客姓名: _____
邮政编码: _____

售后服务说明

尊敬的用户,非常感谢您使用我们的产品,为了切实保障您的权益,明确经销代理商和公司应当承担产品的维修、更换、退货(简称三包)责任义务,敬请阅读以下事项:


- 产品保修卡,是我公司对其产品提供保修期内免费售后服务的必要凭证。
- 按照谁销售谁负责三包原则,产品出现质量问题凭(产品保修卡)与经销商联系,由经销商对客户提供服务,我公司将对经销商提供服务支持。
- 公司承诺,自售出之日(日期以有效,票据日期为准)起七日内出现质量问题,客户可以选择退货更换及维修,产品超过保修出现质量问题享受终身维修(售后售后服务点只收取元器件材料费);请客户在购买时与经销商认真填好(产品保修卡);
- 下列情形不享受三包服务
 - 超过三包期限的
 - 未按产品使用说明要求使用、维修、保管而造成损坏的
 - 非承担三包的维修者拆动造成损坏的
 - 无(产品保修卡)
 - (产品保修卡)上的内容与产品实物不符或涂改的
 - 因不可抗力造成的
- 以上各事项最终解释权属于本公司所有



neck cooler

— Instructions —

Appearance Description



Features

- Lightweight , compact and portable to free your hands.
- Multi-level air output to meet different usage scenarios.
- Simple bladeless design for safer use.
- Built-in battery for an ultra-long endurance life.

How to Use It


A. How to use it

Open the fan slightly left and right with the air outlet facing upward , hang it on the neck , press the power button , the fan starts to work , and the wind blows from the air outlet to the head , bringing a cool experience .

B. ON-OFF / mode switching


Switch:
Short press the button to boot , long press the button to shut down.

Switching among modes:
Short press the button to switch to Level 1 / Level 2 / Level 3 / long press it for shutdown.



C. Cleaning and maintenance

- Before cleaning the fan , please make sure that the power is off.
- Wipe the fan body and the air outlet with a dry cloth.
- Never clean electrical parts (such as motor , power switch , etc .) of the fan with water or other liquids.
- Never touch the power supply and electrical components with a wet hand or cloth.
- In case of any dust or foreign matter at the air outlet , please remove it in time to prevent it from falling into the air chamber.



D. Instructions for charging

This fan has a built-in battery for an ultra-long endurance life .
Instructions for the indicator status

Indicator Status	Meaning
Red light off	Fully charged
Red light is always on	The fan is being charged
Steady green	Fan working status
Light is not on	Shut down or the fan stops working due to lack of power

Antionttes

- when using, the hair should avoid the air inlet, so as to avoid the hair from getting involved in the air cavity, endangering its own safety and affecting the product life.
- When the fan is used under normal conditions, when the green light is off, it means that the remaining power is too low and the device needs to be recharged.
- TPE soft materials have a limit in bending, please avoid excessive bending when using.
- It is forbidden to disassemble, impact, squeeze or throw the battery into fire. If there is severe bloating, do not continue to use it. do not place in high temperature environment.

Warnings

- The lithium-ion battery provided for this product isn't designed with the memory function. Overcharging or over-discharging it will affect its service life. Therefore, please charge it and disconnect the power supply after fully charged both in a timely manner.

- Since the fan blade rotates at high speed when the fan is working, never put your fingers into it to avoid dangers.
- As this product is not a toy for children, children below 14 years old should use it under the care of a guardian.
- Do not extrude, disassemble the battery or leave it in a high temperature environment (60°C and above) for a long time, otherwise there may be a risk of leakage or explosion.
- Do not use this product while charging.

Three-guarantee Certificate

- Please keep the warranty card properly as a certificate for maintenance.
- The warranty period is within one year from the date of purchase.
- During the warranty period , if this product breaks down under normal use and is verified by our company, we will provide maintenance and replacement services free of charge.

Free maintenance is not available under the following circumstances

Our products are subject to limited warranty within the warranty period. Equipment failure or damage under the following circumstances is not covered by the limited warranty, and the Company will not undertake the warranty obligation free of charge ;

- Equipment or parts have exceeded the valid warranty period.
- Equipment failure or damage caused by the customer's incorrect installation, storage and use according to the instructions.
- Equipment failure or damage caused by disassembly by non-authorized agencies or personnel of the Company.
- Equipment failure or damage caused by unexpected factors or human factors (including but not limited to operating errors , scratches , handling , bumping , input of inappropriate voltage and current , etc.) .
- It is forbidden to disassemble , impact , squeeze or throw the battery into fire.

If there is severe bloating, do not continue to use it. Do not place in high temperature environment.

Product Parameters

Product name : neck cooler
Input : 5.0V≈1.0A
Battery cell : lithium-ion battery
power : 3W(MAX)
Product weight : 250g
Charging time : About 3-5 hours (depending on built-in battery)
Usage time : 3-16hours(depending on the sevice at different levels/usage scenarios)
Dimension : 200 (L) × 192 (W) × 60 (H) mm

Packing Accessories

Lighted neck cooler * 1
Type-C USB cable * 1
User manual * 1
CPE bag * 1

Certificate of Quality
Inspector 01 Pass

Warranty Card

Model : _____
Purchase Date : _____
Distributor : _____
Invoice Date : _____
Tel : _____
Customer Name : _____
Zip code : _____

After-sales service instructions

Dear users, thank you very much for using our products. In order to protect your rights and interests, it is clear that distribution agents and companies should bear the responsibility of product maintenance, replacement and return. Please read the following items:

- Product warranty card, is our products to provide free after-sales service during the warranty period of the necessary proof.
- According to who sells who is responsible for the three guarantees principle, the product quality problem with (product guarantee card) contact with the dealer, by the dealer to provide the service to the customer, my company provides the service support to the dealer.
- The company undertakes that if a quality problem occurs within seven days from the date of sale (the date is valid, the date of the bill shall prevail), the customer may choose to return the goods to replace the goods and maintain the warranty. Products beyond warranty quality problems enjoy life-long maintenance (each after-sales service points only charge for component materials); customers are requested to purchase with the dealer to All in product warranty card);
- Below cases are not included in the warranty
 - Exceed the service time
 - Damage caused by failure to use, maintain or keep in accordance with the requirements of the instructions for the use of the product
 - A person who is not responsible for warranty will remove and cause damage
 - No warranty card
 - The warranty card where the contents of the card are not in accordance with the physical object of the product or are altered
 - Caused by force majeure
- All rights reserved.